



Преобразователь температуры SINEAX V608

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81

Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54

Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: cmn@nt-rt.ru || www.camille-bauer.nt-rt.ru

использовано с разрешения официального
дистрибутора АО «ЮЕ-Интернейшнл»

SINEAX V 608, Programmable Two-wire Temperature Transmitter for RTD and TC Inputs

for rail mounting in housing K17



Application

SINEAX V 608 is a two-wire transmitter. It is designed for measuring temperature in combination with thermocouples or resistance thermometers. Thermocouple non-linearities are automatically compensated. The output signal is a current in the range 4...20 mA.

The input variable and measuring range are programmed with the aid of a PC and the corresponding software.

The sensor circuit is monitored for open and short-circuits and the output responds in a defined manner if one is detected.

The power supply (12...30 V DC) is connected together with the signal by the two leads connected to the measurement output (loop powered).




Fig. 1. Measuring transmitter SINEAX V 608 in housing K17.

Features / Benefits

- Input variable and measuring range programmed using PC / Simplifies project planning and engineering, short delivery times, low stocking levels

Measured variables	Measuring ranges		
	Limits	Min. span	Max. span
Temperatures with resistance thermometers for two, three or four wire connection			
Pt100, IEC 60 751	-200 to 850 °C	50 K	850 K
Ni100, DIN 43 760	-60 to 250 °C	50 K	250 K
Temperatures with thermocouples			
Type B, E, J, K, N, R, S, T acc. to IEC 60 584-1	acc. to type	2 mV	80 mV
Type L and U, DIN 43 710			
Type W5 Re/W26 Re			
Type W3 Re/W25 Re acc. to ASTM E 988-90			

- Two-wire transmitter for installation in the process environment
- Open and short-circuit sensor circuit supervision / Defined output response should the supervision pick-up
- Programmable with or without power supply connection
- Compact design / Makes maximum use of available space
- Available in type of protection "Intrinsic safety" EEx ia IIC T6 (see "Table 5: Data on explosion protection")

Standard versions

The following versions are available as standard versions already programmed for the **basic** configuration. It is only necessary to quote the **Order No.:**

Table 1:

Version	Cold junction compensation	Order Code	Order No.
Standard, not electrically isolated	incorporated	608-810	141 515
EEx ia IIC T6, not electrically isolated		608-830	141 523

Please complete the Order Code 608-8.1. according to "Table 3: Specification and ordering information" for versions with user-specific input ranges.

Basic configuration:

Measuring input	Pt 100 for three -wire connection
Measuring range	0 ... 600 °C
Measuring output	4 ... 20 mA, linearised with temperature
Open-circuit supervision	Output 21.6 mA
Response time	Approx. 1.5/2 s (Table 2)
Mains ripple suppression	For frequency 50 Hz

SINEAX V 608, Programmable Two-wire Temperature Transmitter for RTD and TC Inputs

Programming

A PC, the programming cable PK 610 plus ancillary cable and the programming software V 600 *plus* are required to program the transmitter. (Details of the programming cable and the software are in be found in the separate data sheet: PK 610 Le.)

The connections between

"PC ↔ PK 610 ↔ SINEAX V 608" can be seen from Fig. 2. The transmitter can be programmed either with or without the power supply connected.

The software V 600 *plus* is supplied on one CD and runs under Windows 3.1x, 95, 98, NT and 2000.

The programming cable PK 610 adjusts the signal level between the PC and the transmitter SINEAX V 608.

The programming cable PK 610 is used for programming both standard and Ex versions.

It is possible to programme the temperature transmitter installed into the hazardous area.




Fig. 2. Example of the set-up for programming a SINEAX V 608 without the power supply. For this case the switch on the interface must be set to "ON".

Technical data

Measuring input →

Temperature with resistance thermometers

Measuring range limits:

See table 4

Resistance types:

Type Pt 100 (IEC 60 751)
Type Ni 100 (DIN 43 760)
other sensor types configurables

Measuring current:

≤ 0.20 mA

Standard circuit:

1 resistance thermometer for
two-, three- or four-wire connection

Input resistance:

R_i > 10 MΩ

Lead resistance:

≤ 30 Ω per lead

Temperature with thermocouple

Measuring range limits:

See Table 4

Thermocouple pairs:

Type B: Pt30Rh-Pt6Rh (IEC 584)
Type E: NiCr-CuNi (IEC 584)
Type J: Fe-CuNi (IEC 584)
Type K: NiCr-Ni (IEC 584)
Type L: Fe-CuNi (DIN 43710)
Type N: NiCrSi-NiSi (IEC 584)
Type R: Pt13Rh-Pt (IEC 584)
Type S: Pt10Rh-Pt (IEC 584)
Type T: Cu-CuNi (IEC 584)
Type U: Cu-CuNi (DIN 43710)
Type W5 Re/W26 Re (ASTM)
Type W3 Re/W25 Re E 988-90

Standard circuit:

1 thermocouple, **internal** cold junction compensation with built-in Pt 100
or
1 thermocouple, **external** cold junction compensation

Input resistance: R_i > 10 MΩ

Cold junction compensation:

Internal:

Internal or external

With built-in Pt 100
or
with Pt 100 connected to the terminals

External:

Via cold junction thermostat
0 ... 60 °C, configurable

Measuring output ↗

Output signal I_A:

(output/powering circuit)

Impressed DC current,
linear with temperature


Standard range:

4...20 mA, 2-wire technique

External resistance (load):

$$R_{\text{ext max.}} = \frac{\text{Power supply [V]} - 12 \text{ V}}{\text{Max. output current [mA]}}$$

Load max. [Ω] with
20 mA output



Residual ripple in
output current:
< 1% p.p.

SINEAX V 608, Programmable Two-wire Temperature Transmitter for RTD and TC Inputs

Table 2: Response time

Measuring mode	Open sensor circuit	Short-circuit	Possible response times approx. [s]							
			*)		Option					
TC int. comp.	aktiv	—	1.5	2.5	3.5	6.5	11	20.5	40	
TC int. comp.	off	—	1.5	2.5	3.5	6.5	13.5	24.5	49.5	
TC ext. comp.	aktiv	—	1.5	2.5	3.5	6.5	11	20.5	40	
TC ext. comp.	off	—	1.5	2.5	4	6.5	13.5	24.5	48.5	
RTD 2L	aktiv	—	2	2.5	3	5	9.5	17.5	33.5	
RTD 3L, 4L	aktiv	aktiv	2	2.5	4	6.5	11.5	21	40.5	
RTD 2L,3L,4L	off	off	1.5	2.5	3.5	7.5	14	26.5	50.5	

*) Standard values, also valid for basic configuration

Programming connector

Interface: Serial interface

Accuracy data (acc. to EN/IEC 60 770-1)

Reference value: Measuring span
Basic accuracy: Error limits $\leq \pm 0.2\%$ at reference conditions

Reference conditions

Ambient temperature 23 °C
Power supply 18 V DC
Output burden 250 Ω
Settings Pt100, 3-wire, 0...600 °C

Additional errors (additive)

Low measuring ranges
Voltage measurement $\pm 5 \mu\text{V}$
at measuring spans < 10 mV
Resistance thermometer $\pm 0.3 \text{ K}$
at measuring spans < 400 °C

Thermocouple
Type U, T, L, J, K, E $\pm 0.1 \text{ K}$
at measuring spans < 200 °C
Type N $\pm 0.13 \text{ K}$
at measuring spans < 320 °C
Type S, R $\pm 0.42 \text{ K}$
at measuring spans < 1000 °C
Type B $\pm 0.6 \text{ K}$
at measuring spans < 1400 °C

High initial value
(Additional error = Factor · initial value)
Factor
Voltage measurement $\pm 0.1 \mu\text{V} / \text{mV}$
Resistance thermometer $\pm 0.00075 \text{ K} / ^\circ\text{C}$

Thermocouple
Type U, T, L, J, K, E $\pm 0.0006 \text{ K} / ^\circ\text{C}$
Type N $\pm 0.0008 \text{ K} / ^\circ\text{C}$
Type S, R $\pm 0.0025 \text{ K} / ^\circ\text{C}$
Type B $\pm 0.0036 \text{ K} / ^\circ\text{C}$

Influence of lead resistance
at resistance thermometer $\pm 0.01\% \text{ per } \Omega$

Internal cold junction compensation

$\pm 0.5 \text{ K}$

Linearisation

$\pm 0.3\%$

Influencing factors

Temperature $\leq \pm (0.15\% + 0.15 \text{ K}) \text{ per } 10 \text{ K}$ with temperature measurement
 $\leq \pm (0.15\% + 12 \mu\text{V}) \text{ per } 10 \text{ K}$ with voltage measurement

 Power supply influence (power supply on terminals) $\leq \pm 0.005\% \text{ per V}$
 Long-time drift $\leq \pm 0.1\%$
 Common and transverse mode influence $\leq \pm 0.2\%$

Open and short-circuit sensor circuit supervision

Signalling modes:
 Output signal programmable to
 ... the value the output had immediately prior to the open or short-circuit (hold value)
 ... a value between 4 and 21.6 mA

Power supply →○

DC voltage:
 Supply 12...30 V DC
 max. residual ripple 1% p.p.
 (supply must not fall below 12 V)
 Protected against wrong polarity

Installation data

Housing:
 Housing K17 for rail mounting
 Dimensions see section "Dimensional drawings"

 Material of housing:
 Polyamide
 Flammability Class V2 acc. to UL 94, self-extinguishing, non-dripping, free of halogen

 Mounting:
 For snapping
 – onto rail G
 acc. to EN 50 035 – G32
 or
 – onto top-hat rail
 acc. to EN 50 022 (35 × 15 mm or 35 × 7.5 mm)

Standards

Electromagnetic compatibility:
 The standards EN 50 081-2 and EN 50 082-2 are observed

 Intrinsically safe:
 Acc. to EN 50 020

 Protection (acc. to IEC 529 resp. EN 60 529):
 Housing IP 40
 Terminals IP 20

SINEAX V 608, Programmable Two-wire Temperature Transmitter for RTD and TC Inputs

Electrical standards:	Acc. to IEC 1010 resp. EN 61 010	Storage temperature range:	-40 to + 80 °C
Ambient conditions		Annual mean relative humidity:	≤ 75%, no moisture condensation
Climatic rating:	IEC 60 068-2-1/2/3		
Ambient temperature range:	-25 to + 80 °C at NEx and Ex (T4) at Ex (T6) dependent of Pi, see EC-type-examination Certificate		

Table 3: Specification and ordering information (see also Table 1: Standard versions)

Description	*Blocking code	No-go with blocking code	Article No./Feature
SINEAX V 608	Order Code V 608 - xxxx xxxx xxx		608 –
Features, Selection			
1. Housing			
Housing K17 for rail mounting			8
2. Version			
Standard, not electrically isolated			1
EEx ia IIC T6, not electrically isolated			3
3. Configuration	G		0
Basic configuration, programmed (Pt100, three-wire, 0 ... 600 °C) All types with basic configuration are available as standard versions, see table 1, specification complete!			
Programmed to order The following features 4 to 11 must be fully specified!			1
4. Measuring unit			
Temperatures in °C			1
Temperatures in °F		G	2
Temperatures in K		G	3
5. Measuring mode, input connection			
Thermocouple			
Internal cold junction compensation, with built-in Pt100	T	G	1
External cold junction compensation t_K	T	G	2
Specify external cold junction temperature t_K (in °C, °F or K, acc. to specification in Feature 4) any value between 0 and 60 °C or equivalent			
Resistance thermometer			
Two-wire connection, R_L [Ω]	R	G	3
Specify total lead resistance R_L [Ω], any value between 0 and 60 Ω			
Three-wire connection, $R_L \leq 30 \Omega/\text{wire}$	R		4
Four-wire connection, $R_L \leq 30 \Omega/\text{wire}$	R	G	5
6. Sensor type / measuring range			
Sensor type / beginning ... end value of measuring range			
RTD PT 100	Range	T	1
RTD Ni 100	Range	GT	2
RTD Pt ... [Ω]	Range	GT	3
RTD Ni ... [Ω]	Range	GT	4

SINEAX V 608, Programmable Two-wire Temperature Transmitter for RTD and TC Inputs

Description	*Blocking code	No-go with blocking code	Article No./ Feature
SINEAX V 608			608 –
Features, Selection			
6. Sensor type / measuring range (continuation)			
Sensor type / beginning ... end value of measuring range			
TC Type B	Range	GR	B
TC Type E	Range	GR	E
TC Type J	Range	GR	J
TC Type K	Range	GR	K
TC Type L	Range	GR	L
TC Type N	Range	GR	N
TC Type R	Range	GR	R
TC Type S	Range	GR	S
TC Type T	Range	GR	T
TC Type U	Range	GR	U
TC W5-W26Re	Range	GR	W
TC W3-W25Re	Range	GR	X
Specify measuring range in [°C], [°F] or [K]; refer to table 4 for the operating limits for each type of sensor.			
Lines 3 and 4: Specify resistance in Ω at 0 °C, any value between 50 and 4000 Ω			
7. Output characteristic			
Standard 4 ... 20 mA			0
Inversely 20 ... 4 mA		G	1
8. Open and short-circuit sensor signalling			
Output response for an open or short-circuit* sensor			
Output 21.6 mA			0
Output (any value between 4 and < 21.6 mA)	[mA]	G	1
Hold output at last value		G	2
No signal		G	A
* The short-circuit signal is only active for the RTD measuring mode $\geq 100 \Omega$ at 0 °C and three or four-wire connection			
9. Output time response			
Standard setting time approx. 2 s			0
Setting time (admissible values see Table 2)	[s]	G	9
10. Mains ripple suppression			
Frequency 50 Hz			0
Frequency 60 Hz		G	1
11. Test certificate			
Without test certificate			0
Test certificate in German		G	D
Test certificate in English		G	E

*Lines with letter(s) under "no-go" cannot be combined with preceding lines having the same letter under "SCODE".

SINEAX V 608, Programmable Two-wire Temperature Transmitter for RTD and TC Inputs

Table 4: Temperature measuring ranges

Measuring ranges [°C]	Resistance thermometers		Thermocouples											
	Pt100	Ni100	B	E	J	K	L	N	R	S	T	U	C ¹⁾	D ²⁾
0 ... 40	X			X	X		X							
0 ... 50	X	X		X	X	X	X				X	X		
0 ... 60	X	X		X	X	X	X				X	X		
0 ... 80	X	X		X	X	X	X	X			X	X		
0 ... 100	X	X		X	X	X	X	X			X	X		
0 ... 120	X	X		X	X	X	X	X			X	X		
0 ... 150	X	X		X	X	X	X	X			X	X	X	
0 ... 200	X	X		X	X	X	X	X			X	X	X	X
0 ... 250	X	X		X	X	X	X	X			X	X	X	X
0 ... 300	X			X	X	X	X	X	X	X	X	X	X	X
0 ... 400	X			X	X	X	X	X	X	X	X	X	X	X
0 ... 500	X			X	X	X	X	X	X	X		X	X	X
0 ... 600	X			X	X	X	X	X	X	X		X	X	X
0 ... 800	X		X	X	X	X	X	X	X	X			X	X
0 ... 900			X	X	X	X	X	X	X	X			X	X
0 ... 1000			X	X	X	X		X	X	X			X	X
0 ... 1200			X		X			X	X	X			X	X
0 ... 1500			X						X	X			X	X
0 ... 1600			X						X	X			X	X
0 ... 1800			X										X	X
0 ... 2000													X	X
50 ... 150	X	X		X	X	X	X					X	X	
100 ... 300	X			X	X	X	X					X	X	X
200 ... 500	X			X	X	X	X	X	X			X	X	X
300 ... 600	X			X	X	X	X	X	X	X		X	X	X
600 ... 900			X	X	X	X	X	X	X	X			X	X
600 ... 1000			X	X	X	X		X	X	X			X	X
900 ... 1200			X		X	X		X	X	X			X	X
600 ... 1600			X						X	X			X	X
600 ... 1800			X										X	X
-10 ... 40	X	X		X	X	X	X						X	
-30 ... 60	X	X		X	X	X	X	X	X			X	X	
Measuring range limits [°C]	-200 to 850	-60 to 250	0 to 1820	-270 to 1000	-210 to 1200	-270 to 1372	-200 to 900	-270 to 1300	-50 to 1769	-50 to 1769	-270 to 400	-200 to 600	0 to 2315	0 to 2315
	$\Delta R \text{ min. } 15 \Omega$ at final value ³⁾ $\leq 400 \Omega$ $\Delta R \text{ min. } 150 \Omega$ at final value $> 400 \Omega$ max. final value 4000Ω initial value $\frac{\text{initial value}}{\Delta R} \leq 10$		$\Delta U \text{ min } 2 \Delta R, \text{ max. } 80 \text{ mV}$ $\frac{\text{Initial value}}{\Delta U} \leq 10$											

¹⁾ W5 Re W26 Re (ASTM E 988-90)

²⁾ W3 Re W25 Re (ASTM E 988-90)

³⁾ For two-wire connection, the final value is made up of the measured final value [Ω] plus the total resistance of the leads.

SINEAX V 608, Programmable Two-wire Temperature Transmitter for RTD and TC Inputs

Table 5: Data on explosion protection  II 2 (1) G

Order code	Type of protection Marking	Electrical data cc. to Certificate		Certificate	Mounting location
		Sensor input	Output		
608-83	EEx ia IIC T6	$U_o = 6 \text{ V}$ $I_o = 15 \text{ mA}$ $P_o = 39 \text{ mW}$ $C_o = 990 \text{ nF}$ $L_o = 5 \text{ mH}$	$U_i = 30 \text{ V}$ $I_i = 160 \text{ mA}$ $P_i = \text{max. } 1 \text{ W}^*$ $C_i = 0$ $L_i = 0$	EC-type-examination Certificate ZELM 01 ATEX 0052	Within the hazardous area, zone 1 and 2**

* Ambient temperature Ex: $-25^\circ\text{C} \dots \text{max. } 57^\circ\text{C}$ (dependent on P_i , see EC-type-examination Certificate)

** It is permissible for the sensor circuit to enter Zone 0, however, EN 50 284 and any applicable national standards must be observed.

Table 6: Accessories and spare parts


Description	Order No.
Programming cable PK 610	137 887
Ancillary cable SINEAX Type V 608	141 416
Configuration Software V 600 plus for SINEAX V 608, VK 616 and V 624 Windows 3.1x, 95, 98, NT and 2000 on CD in German, English, French, Spanish, Italian and Dutch In addition, the CD contains all configuration programmes presently available for Camille Bauer products	146 557
Operating Instructions V 608-8 Bd in German	141 953
Operating Instructions V 608-8 Bf in French	142 068
Operating Instructions V 608-8 Be in English	142 117

Standard accessories

- 1 Operating Instructions in German, French and English
- 1 Type examination certificate (only for "intrinsically safe" explosion-proof devices)

SINEAX V 608, Programmable Two-wire Temperature Transmitter for RTD and TC Inputs

Electrical connections



→ = Measuring input

→ = Two-wire measuring output (measuring circuit, 4 ... 20 mA signal)

→ = Power supply 12 ... 30 V DC

Dimensional drawings




Fig. 3. SINEAX V 608 in housing **K17**
clipped onto a top-hat rail EN 50 022 – 35 x 7.5.




Fig. 4. SINEAX V 608 in housing **K17**
clipped onto a rail "G" EN 50 035 - G32.

 **CAMILLE BAUER**
Rely on us.

По вопросам продажи и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81

Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54

Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: cmn@nt-rt.ru || www.camille-bauer.nt-rt.ru

PROCESS CONTROL ENGINEERING



ANGULAR POSITION ENGINEERING



HEAVY CURRENT ENGINEERING

